




WALKMAN
NW-WS413/WS414

4-580-536-12(1)


©2016 Sony Corporation Printed in Malaysia






1










2







3





Ⓜ "On"



Windows
Music Center for PC
<http://www.sony.net/smc4pc/>

Mac
Content Transfer for Mac
<http://www.sony.net/ct-mac/>

i

http://rd1.sony.net/help/dmp/nwws410/h_ww/